

C3-400 Installation Guide

Vision: 1.0.1 Date: Oct. 2010

1. Cautions


⚠ Please note the following cautions. Mis-operation may lead to personal injury or equipment failure:

- 1) Do not energize the system before installation is complete; never carry out installation activities when the system is energized.
- 2) All peripheral devices must be grounded.
- 3) It is preferred that all wires run through PVC or galvanized conduit.
- 4) It is strongly recommended that the length of the exposed part of any connection cable not be longer than 4 mm. Professional clamping tools may be used to avoid unintentional contact of exposed wires to avoid short-circuit or communication failure.
- 5) It is recommended that card readers and buttons be installed at a height of 1.4m-1.5m above ground.
- 6) It is recommended to use the accompanying power supply for the control panel, and external power supply for each lock.


Description of normal working state:

Connect the system to the power supply. If the system works properly, the POWER indicator (red) is lit constantly and the RUN indicator (green) flashes.

2. Components



3. Get through the thread hole



4. LED Indicators, Wires, Auxiliary Input and Output

Notes:

1) Meaning of LED indicators:

LINK indicator (green): always (green) indicates TCP/IP communication is proper;

ACT indicator (yellow): flashing indicates data is transmitting through TCP/IP communication.

TX indicator (yellow): flashing indicates it is sending data through RS485 communication.

RX indicator (green): flashing indicates it is receiving data through RS485 communication.

Auxiliary output indicator (green): always (green) indicates it is in use.

Lock indicator (green): always (green) indicates lock is open.

POWER indicator (red): always (red) indicates control panel power is on.

RUN indicator (green): flashing indicates the system works normally.

CARD indicator (yellow): flashing indicates CARD is punched on reader.

2) Recommended use of wires:

A Use 2-conductor power cord


B Use 6-conductor wire between Wiegand reader and control panel (RVVP 6x0.5mm) (choose the appropriate cord for the interface you connect, such as 6, 8, 10 cord)

C Use 4-conductor lock power cord (RVV 4x0.75mm)

D Use 2-conductor switch power cord (RVV 2*0.5mm)

3) The auxiliary input may be connected to infrared body detectors, alarms, switches, etc.

4) The auxiliary output may be connected to door bells, alarms, etc.



Set RS485 address through DIP switch:

- Places 1-6 on the DIP switch are for setting the number of control panels when communicating through RS485. It is adapted for binary coding and little endian, the address represented by places 1-6 are shown in figure (5-1).
- Before setting the address, keep the system power off. Jump places 1-6 to desired status. The address number cannot be the same as another one in the network. For example: to set the device number as 39 (39=1+2+4+32), the corresponding RS485 code is 111001, then Jump place 1, 2, 3 and 6 at "ON" status.



- Place 7 is for restoring factory default settings. Jump it three times within 10 seconds and restart the system, then all information in control panel RAM will be cleared and the system restored to factory default settings.
- Place 8 is for setting terminal resistance when communicating through RS485. Jump it at "ON" status, then it is equivalent to having a terminal resistance of 120 ohm between 485+ and 485-.

Location of DIP switch.





Figure (5-1)

1) Control panel provides lock control output interfaces. For NO lock, it is open when power is on and closed when power is off, so COM and NO interfaces should be used; For NC lock, it is open when power is off and closed when power is on, so COM and NC interfaces should be used.

2) Control panel supports "dry mode" and "wet mode" by setting the jumper. It is "wet mode" when connecting "V+ V-" Input interfaces to supply power for locks, short 2-3 and 4-5. Equipment factory default setting is dry mode. For setting "dry mode" and "wet mode", please refer to <<C3-100/200/400 access control panel installation instructions>>.


3) When the Electrical Lock is connected to the Access Control System, you need to parallel one FR107 diode (included in the package) to prevent the self-induced EMF affecting the system, do not reverse the polarities.



The background PC software is able to communicate with the system according to two protocols (RS485 and TCP/IP) for data exchange and remote management. The communication cable should be as far away from high-voltage lines as possible. Do not keep the communication cable parallel to the power cords or bind them together.


1. TCP/IP Communication

Switch




2. RS485 Communication

GND 485 serial line
485- 485 Converter
485+



PC



Notes:

- Internationally accepted RVSP (shielded twisted-pair) wires should be used for communication to effectively avoid interference. RS485 communication wires should be connected by means of bus cascade connection.
- Considering stability of communication, it is recommended the length of RS485 bus be less than 600m
- One RS485 BUS may hold 63 control panel units, but it is not recommended to connect more than 32 access control panels units.
- To enhance the stability of communication when the bus is longer than 300m, it is necessary to keep place 8 of the DIP switches for the first and the last control panel at "ON" status. As shown in the figure above, place 8 of the DIP switches of units #1 and #8 is placed at "ON" status.

